

Revealing Embedded Fingerprints: Deriving intelligence from USB stack interactions



Andy Davis, Research Director NCC Group





UK Offices

Manchester - Head Office
Cheltenham
Edinburgh
Leatherhead
London
Thame

European Offices

Amsterdam - Netherlands
Munich - Germany
Zurich - Switzerland



North American Offices

San Francisco
Atlanta
New York
Seattle



Australian Offices

Sydney


Agenda

Part One:

- Overview of the USB enumeration phase
- Different USB stack implementations
- USB testing platform
- Installed drivers and supported devices
- Fingerprinting USB stacks and OS versions

Part Two:

- The Windows 8 RNDIS kernel pool overflow
- Challenges faced when exploiting USB bugs
- Conclusions



Part One: Information gathering

- Why do we care?
- If you connect to a device surely you already know the platform?
- Embedded devices are mostly based on Linux anyway aren't they?
- May provide information useful for other attacks



USB Background stuff



Overview of the USB enumeration phase

- What is enumeration for?
 - Assign an address
 - Speed of communication
 - Power requirements
 - Configuration options
 - Device descriptions
 - Class drivers
- Lots of information exchange – implemented in many different ways



The USB enumeration phase

LS	Control Transfer	Addr	Endp	Data (18 bytes)	Status
←	Get Device Descriptor	0x00	0x0	12 01 10 01 00 00 00 08...	OK

LS	Control Transfer	Addr	Endp	Data (0 bytes)	Status
→	Set Address (0x01)	0x00	0x0		OK

LS	Control Transfer	Addr	Endp	Data (18 bytes)	Status
←	Get Device Descriptor	0x01	0x0	12 01 10 01 00 00 00 08...	OK

LS	Control Transfer	Addr	Endp	Data (34 bytes)	Status
←	Get Configuration Descriptor	0x01	0x0	09 02 22 00 01 01 00 A0...	OK

LS	Control Transfer	Addr	Endp	Data (4 bytes)	Status
←	Get String Descriptor 0	0x01	0x0	04 03 09 04	OK

LS	Control Transfer	Addr	Endp	Data (48 bytes)	Status
←	Get String Descriptor 2	0x01	0x0	30 03 44 00 65 00 6C 00...	OK

LS	Control Transfer	Addr	Endp	Data (18 bytes)	Status
←	Get Device Descriptor	0x01	0x0	12 01 10 01 00 00 00 08...	OK

LS	Control Transfer	Addr	Endp	Data (9 bytes)	Status
←	Get Configuration Descriptor	0x01	0x0	09 02 22 00 01 01 00 A0...	OK

LS	Control Transfer	Addr	Endp	Data (34 bytes)	Status
←	Get Configuration Descriptor	0x01	0x0	09 02 22 00 01 01 00 A0...	OK

LS	Control Transfer	Addr	Endp	Data (0 bytes)	Status
→	Set Configuration (0x01)	0x01	0x0		OK

Enumeration phase peculiarities

- Why is the device descriptor initially requested twice?
- Why are there multiple requests for other descriptors?
- Class-specific descriptors:


LS	Control Transfer	Addr	Endp	Data (84 bytes)	Status
←	Get HID Report Descriptor	0x01	0x0	05 01 09 06 A1 01 05 07...	OK

LS	Control Transfer	Addr	Endp	Data (1 byte)	Status
→	Set Report (HID)	0x01	0x0	00	OK



Different USB stack implementations

- Typical components of a USB stack
- Windows USB driver stack
- Linux USB stack
- Embedded Access USB stack




Typical components of a USB stack


- Host Controller hardware
- USB System software:
 - Host Controller Driver – Hardware Abstraction Layer
 - USB Driver
- Class drivers
- Application software




Windows USB driver stack




Linux USB stack



Embedded Access USB stack




Interacting with USB



USB interaction requirements

- Need to capture and replay USB traffic
- Full control of generated traffic
- Class decoders extremely useful
- Support for Low/High/Full speed required
- USB 3.0 a bonus



USB testing – gold-plated solution

- Commercial test equipment



\$1400



\$20,000




USB testing – the cheaper approach


- Facedancer (<http://goodfet.sourceforge.net/hardware/facedancer21>)



Best solution: A combination of both



- Device data can be carefully crafted
- Host response data can be captured
- Microsecond timing is also recorded
- All class-specific data is decoded



Information enumeration




Target list

- Windows 8
- Ubuntu Linux 12.04 LTS
- Apple OS X Lion
- FreeBSD 5.3
- Chrome OS
- Linux-based TV STB



Installed drivers and supported devices

- Enumerating supported class types – standard USB drivers
- Enumerating all installed drivers
- Other devices already connected



Enumerating supported class types

Where is USB class information stored?

Field	Value	Meaning
bLength	18	Valid Length
bDescriptorType	1	DEVICE
bcdUSB	0x0110	Spec Version
bDeviceClass	0x00	Class Information in Interface Descriptor
bDeviceSubClass	0x00	Class Information in Interface Descriptor

Device Descriptor

Field	Value	Meaning
bLength	9	Valid length
bDescriptorType	4	INTERFACE
bInterfaceNumber	0	Zero-based Number of this Interface.
bAlternateSetting	0	Value used to select this alternative setting for the interface identified in the prior field
bNumEndpoints	1	Number of endpoints used by this interface (excluding endpoint zero).
bInterfaceClass	0x03	HID
bInterfaceSubClass	0x01	Boot Interface

Interface Descriptor

Installed drivers and supported devices

- Drivers are referenced by class (Device and Interface descriptors)
- Also, by VID and PID:

idVendor	0x090C	Silicon Motion, Inc. - Taiwan
idProduct	0x1000	Memory Bar

- For each device class VID and PID values can be brute-forced (can easily be scripted using Facedancer)
- Valid PIDs and VIDs are available (<http://www.linux-usb.org/usb.ids>)



Enumerating installed drivers

Not installed:



HS	Control Transfer	Addr	Endp	Data (18 bytes)	Status
←	Get Device Descriptor	0x00	0x0	12 01 00 02 00 00 00 40...	OK
→	Set Address (0x1f)	0x00	0x0		OK
←	Get Device Descriptor	0x1F	0x0	12 01 00 02 00 00 00 40...	OK
←	Get Configuration Descriptor	0x1F	0x0	09 02 2E 00 01 01 00 80...	OK
←	Get Configuration Descriptor	0x1F	0x0	09 02 2E 00 01 01 00 80...	OK
←	Get String Descriptor 0	0x1F	0x0	04 03 09 04	OK
←	Get String Descriptor 2	0x1F	0x0	2A 03 38 00 30 00 32 00...	OK
←	Get String Descriptor 1	0x1F	0x0	12 03 52 00 65 00 61 00...	OK
←	Get String Descriptor 3	0x1F	0x0	1A 03 30 00 30 00 65 00...	OK
→	Set Configuration (0x01)	0x1F	0x0		OK

All communication stops after "Set Configuration"

Installed:



LS	Control Transfer	Addr	Endp	Data (18 bytes)	Status
←	Get Device Descriptor	0x00	0x0	12 01 10 01 00 00 00 08...	OK
→	Set Address (0x02)	0x00	0x0		OK
←	Get Device Descriptor	0x02	0x0	12 01 10 01 00 00 00 08...	OK
←	Get Configuration Descriptor	0x02	0x0	09 02 22 00 01 01 00 A0...	OK
←	Get Configuration Descriptor	0x02	0x0	09 02 22 00 01 01 00 A0...	OK
←	Get String Descriptor 0	0x02	0x0	04 03 09 04	OK
←	Get String Descriptor 2	0x02	0x0	30 03 44 00 65 00 6C 00...	OK
←	Get String Descriptor 1	0x02	0x0	0A 03 44 00 65 00 6C 00...	OK
→	Set Configuration (0x01)	0x02	0x0		OK
→	Set Idle (HID) Indefinite, All	0x02	0x0		OK
←	Get HID Report Descriptor	0x02	0x0	05 01 09 06 A1 01 05 07...	OK
→	Set Report (HID)	0x02	0x0	00	OK

Sniffing the bus - Other connected devices

- Data from other devices will be displayed on other addresses

FS	Bulk Transfer (SPLIT)	Addr	Endp	Data (0 bytes)	Status
←	Class Transfer	0x08	0x2		OK

HS	Control Transfer	Addr	Endp	Data (4 bytes)	Status
→	Vendor Reques	0x04	0x0	7F 54 12 4C	OK

FS	Bulk Transfer (SPLIT)	Addr	Endp	Data (0 bytes)	Status
←	Class Transfer	0x08	0x2		OK

FS	Bulk Transfer (SPLIT)	Addr	Endp	Data (0 bytes)	Status
←	Class Transfer	0x08	0x2		OK



Fingerprinting USB stacks and OS versions

- Descriptor request patterns
- Timing information
- Descriptor types requested
- Responses to invalid data
- Order of Descriptor requests



Matching req. patterns to known stacks

Linux-based TV STB

HS	Control Transfer	Addr	Endp	Data (1 byte)	Status
←	Get Max LUN (Mass Storage)	0x21	0x0	00	OK
→	Bulk Transfer	Addr	Endp	Data (31 bytes)	Status
	CBW: INQUIRY	0x21	0x2	55 53 42 43 01 00 00 00...	OK
←	Bulk Transfer	Addr	Endp	Data (36 bytes)	Status
	MSC Data In	0x21	0x1	00 80 04 02 1F 73 8D 89...	OK
←	Bulk Transfer	Addr	Endp	Data (13 bytes)	Status
	CSW - Status:Passed	0x21	0x1	55 53 42 53 01 00 00 00...	OK
→	Bulk Transfer	Addr	Endp	Data (31 bytes)	Status
	CBW: TEST UNIT READY	0x21	0x2	55 53 42 43 02 00 00 00...	OK
←	Bulk Transfer	Addr	Endp	Data (13 bytes)	Status
	CSW - Status:Passed	0x21	0x1	55 53 42 53 02 00 00 00...	OK
→	Bulk Transfer	Addr	Endp	Data (31 bytes)	Status
	CBW: READ CAPACITY(10)	0x21	0x2	55 53 42 43 03 00 00 00...	OK
←	Bulk Transfer	Addr	Endp	Data (8 bytes)	Status
	MSC Data In	0x21	0x1	00 77 7F FF 00 00 02 00	OK
←	Bulk Transfer	Addr	Endp	Data (13 bytes)	Status
	CSW - Status:Passed	0x21	0x1	55 53 42 53 03 00 00 00...	OK
→	Bulk Transfer	Addr	Endp	Data (31 bytes)	Status
	CBW: MODE SENSE(6)	0x21	0x2	55 53 42 43 04 00 00 00...	OK

Windows 8

HS	Control Transfer	Addr	Endp	Data (1 byte)	Status
←	Get Max LUN (Mass Storage)	0x02	0x0	00	OK
→	Bulk Transfer	Addr	Endp	Data (31 bytes)	Status
	CBW: INQUIRY	0x02	0x2	55 53 42 43 28 1EA8 83...	OK
←	Bulk Transfer	Addr	Endp	Data (36 bytes)	Status
	MSC Data In	0x02	0x1	00 80 04 02 1F 73 8D 89...	OK
←	Bulk Transfer	Addr	Endp	Data (13 bytes)	Status
	CSW - Status:Passed	0x02	0x1	55 53 42 53 28 1EA8 83...	OK
→	Bulk Transfer	Addr	Endp	Data (31 bytes)	Status
	CBW: INQUIRY	0x02	0x2	55 53 42 43 80 3CAB 83...	OK
←	Bulk Transfer	Addr	Endp	Data (36 bytes)	Status
	MSC Data In	0x02	0x1	00 80 04 02 1F 73 8D 89...	OK
←	Bulk Transfer	Addr	Endp	Data (13 bytes)	Status
	CSW - Status:Passed	0x02	0x1	55 53 42 53 80 3CAB 83...	OK
→	Bulk Transfer	Addr	Endp	Data (31 bytes)	Status
	CBW: READ FORMAT CAPACITIES (or VS)	0x02	0x2	55 53 42 43 28 8E B2 83...	OK
←	Bulk Transfer	Addr	Endp	Data (12 bytes)	Status
	MSC Data In	0x02	0x1	00 00 00 08 00 77 80 00...	OK
←	Bulk Transfer	Addr	Endp	Data (13 bytes)	Status
	CSW - Status:Passed	0x02	0x1	55 53 42 53 28 8E B2 83...	OK

Request patterns unique elements?




- Windows 8 (HID) – Three Get Configuration descriptor requests (others have two)
- Apple OS X Lion (HID) – Set Feature request right after Set Configuration
- FreeBSD 5.3 (HID) – Get Status request right before Set Configuration
- Linux-based TV STB (Mass Storage) – Order of class-specific requests

Timing information


Capture13	Capture14	Capture15	Capture16	Capture17*	
#4...18 3.035,975 s	#4...18 3.150,387 s	#4...18 2.846,062 s	#4...18 3.858,656 s	#4...18 3.235,349 s	LS Control Transfer Addr Endp Data (18 bytes) Status ← Get Device Descriptor 0x00 0x0 12 01 10 01 00 00 00 08... OK
#20...25 3.085,990 s	#20...25 3.211,403 s	#20...25 2.893,073 s	#20...25 3.908,665 s	#20...25 3.282,360 s	LS Control Transfer Addr Endp Data (0 bytes) Status ⇒ Set Address (0x01) 0x00 0x0 OK
#26...40 3.104,993 s	#26...40 3.232,408 s	#26...40 2.924,081 s	#26...40 3.939,672 s	#26...40 3.301,365 s	LS Control Transfer Addr Endp Data (18 bytes) Status ← Get Device Descriptor 0x01 0x0 12 01 10 01 00 00 00 08... OK
#41...61 3.110,995 s	#41...61 3.238,409 s	#41...61 2.930,084 s	#41...61 3.945,674 s	#41...61 3.307,366 s	LS Control Transfer Addr Endp Data (34 bytes) Status ← Get Configuration Descriptor 0x01 0x0 09 02 22 00 01 01 00 A0... OK
#62...70 3.122,997 s	#62...70 3.249,410 s	#62...70 2.941,083 s	#62...70 3.957,678 s	#62...70 3.319,369 s	LS Control Transfer Addr Endp Data (4 bytes) Status ← Get String Descriptor 0 0x01 0x0 04 03 09 04 OK
#71...97 3.127,999 s	#71...97 3.254,413 s	#71...97 2.946,086 s	#71...97 3.962,677 s	#71...97 3.324,370 s	LS Control Transfer Addr Endp Data (48 bytes) Status ← Get String Descriptor 2 0x01 0x0 30 03 44 00 65 00 6C 00... OK
#98...112 3.537,094 s	#98...112 3.333,430 s	#98...112 3.026,103 s	#98...112 4.000,685 s	#98...112 3.755,470 s	LS Control Transfer Addr Endp Data (18 bytes) Status ← Get Device Descriptor 0x01 0x0 12 01 10 01 00 00 00 08... OK
#113...124 3.543,095 s	#113...124 3.339,431 s	#113...124 3.032,104 s	#113...124 4.006,686 s	#113...124 3.761,472 s	LS Control Transfer Addr Endp Data (9 bytes) Status ← Get Configuration Descriptor 0x01 0x0 09 02 22 00 01 01 00 A0... OK
#125...145 3.548,096 s	#125...145 3.344,433 s	#125...145 3.037,106 s	#125...145 4.011,687 s	#125...145 3.766,473 s	LS Control Transfer Addr Endp Data (34 bytes) Status ← Get Configuration Descriptor 0x01 0x0 09 02 22 00 01 01 00 A0... OK
#146...151 3.556,098 s	#146...151 3.352,435 s	#146...151 3.045,107 s	#146...151 4.019,689 s	#146...151 3.774,475 s	LS Control Transfer Addr Endp Data (0 bytes) Status ⇒ Set Configuration (0x01) 0x01 0x0 OK
#152...157 3.559,099 s	#152...157 3.355,437 s	#152...157 3.048,109 s	#152...157 4.022,690 s	#152...157 3.777,476 s	LS Control Transfer Addr Endp Data (0 bytes) Status ⇒ Set Idle (HID) Indefinite, All 0x01 0x0 OK
#158...190 3.562,101 s	#158...190 3.358,436 s	#158...190 3.051,109 s	#158...190 4.025,691 s	#158...190 3.780,477 s	LS Control Transfer Addr Endp Data (65 bytes) Status ← Get HID Report Descriptor 0x01 0x0 05 01 09 06 A1 01 05 07... OK
#191...199 3.612,112 s	#191...199 3.403,447 s	#191...199 3.089,118 s	#191...199 4.055,698 s	#191...199 3.834,489 s	LS Control Transfer Addr Endp Data (1 byte) Status ⇒ Set Report (HID) 0x01 0x0 00 OK
=== End of	=== End of	=== End of	=== End of	=== End of Capture ===	

Timing information



Using timing for fingerprinting?

- Large amount of variance over entire enumeration phase:
 - 4.055s, 3.834s, 3.612s, 3.403s, 3.089s
- Much greater accuracy between specific requests:
 - Between String Descriptor #0 and #2 requests - 5002us, 5003us, 5003us, 4999us, 5001us
- If we know the OS we can potentially determine the processor speed




Descriptor types requested

- Microsoft OS Descriptors (MOD)
- Used for “unusual” devices classes
- Devices that support Microsoft OS Descriptors must store a special USB string descriptor in firmware at the fixed string index of 0xEE. The request is:


bmRequestType	bRequest	wValue	wIndex	wLength	Data
1000 0000B	GET_DESCRIPTOR	0x03EE	0x0000	0x12	Returned String

- If a device does not contain a valid string descriptor at index 0xEE, it must respond with a stall packet. If the device does not respond with a stall packet, the system will issue a single-ended zero reset packet to the device, to help it recover from its stalled state (Windows XP only).



Responses to invalid data

- Different USB stacks respond to invalid data in different ways
- Maximum and minimum values
- Logically incorrect values
- Missing data



Invalid data unique elements?


Windows 8 (all versions)

If you send a specific, logically incorrect HID Report descriptor this happens:

Invalid data unique elements?

Windows 8 (all versions)

If you send a specific, logically incorrect HID Report descriptor this happens:



Order of Descriptor requests

- Some USB stacks request data from devices in a different order
- Different drivers may request different descriptors multiple times
- Sometimes Device descriptors are re-requested after enumeration is complete



Part Two: Potentially exploitable USB bugs



The Windows 8 RNDIS kernel pool overflow

- MS13-027
- usb8023x.sys - default (Microsoft-signed) Windows Remote NDIS driver that provides network connectivity over USB.
- When a USB device that uses this driver is inserted into a Windows host, during the enumeration phase the USB Configuration descriptor is requested and parsed
- When the following USB descriptor field is manipulated a Bug check occurs indicating a kernel pool overwrite:
 - Configuration descriptor --> bNumInterfaces field > actual number of USB interfaces

The field is “bNumInterfaces” in Table A2: USB Configuration Descriptor (<http://msdn.microsoft.com/en-us/windows/hardware/gg463298>)



The Bug Check

BAD_POOL_HEADER (19)

The pool is already corrupt at the time of the current request.

<Truncated for brevity>

Arguments:

Arg1: 00000020, a pool block header size is corrupt.

Arg2: 83e38610, The pool entry we were looking for within the page.

Arg3: 83e38690, The next pool entry.

Arg4: 08100008, (reserved)

<Truncated for brevity>

WARNING: SystemResourcesList->Flink chain invalid. Resource may be corrupted, or already deleted.

WARNING: SystemResourcesList->Blink chain invalid. Resource may be corrupted, or already deleted.

SYMBOL_NAME: **usb8023x!SelectConfiguration+1bd**

The SelectConfiguration() function

SelectConfiguration(x)
SelectConfiguration(x)+2
SelectConfiguration(x)+3
SelectConfiguration(x)+5
SelectConfiguration(x)+8
SelectConfiguration(x)+9
SelectConfiguration(x)+A
SelectConfiguration(x)+D
SelectConfiguration(x)+E
SelectConfiguration(x)+11
SelectConfiguration(x)+14
SelectConfiguration(x)+16
SelectConfiguration(x)+1C
SelectConfiguration(x)+1F
SelectConfiguration(x)+26
SelectConfiguration(x)+27
SelectConfiguration(x)+2C
SelectConfiguration(x)+2F
SelectConfiguration(x)+31
SelectConfiguration(x)+37
SelectConfiguration(x)+39
SelectConfiguration(x)+3C
SelectConfiguration(x)+3E

```
mov     edi, edi
push   ebp
mov     ebp, esp
sub     esp, 10h
push   ebx
push   esi
mov     esi, [ebp+ptr_Pool_U802]
push   edi
mov     edi, [esi+1Ch] ; points to start of configuration descriptor
mov     al, [edi+4]   ; al = bNumInterfaces
cmp     al, 2        ; compares with 2 (what it should be)
jb     loc_11877     ; no jump
movzx  eax, al
lea    eax, ds:8[eax*8] ; multiply bNumInterfaces by 8 then add 8 = 24
push   eax
call   _AllocPool@4 ; AllocPool(x)
mov     [ebp+ptr_Pool_U802_24_bytes], eax
test   eax, eax
jz     loc_11877     ; no jump (AllocPool was successful)
xor    ebx, ebx
cmp    [edi+4], bl   ; compares bNumInterfaces with 0
jbe    short loc_1171F ; no jump
mov    esi, eax
```


The crash point

```
SelectConfiguration(x)+9B  get_more_interfaces_to_parse:          ; CODE XREF: SelectConfiguration(x)+CE↓j
SelectConfiguration(x)+9B      push    0FFFFFFFh
SelectConfiguration(x)+9D      push    0FFFFFFFh
SelectConfiguration(x)+9F      push    0FFFFFFFh
SelectConfiguration(x)+A1      push    0
SelectConfiguration(x)+A3      push    ecx
SelectConfiguration(x)+A4      push    edi
SelectConfiguration(x)+A5      push    edi
SelectConfiguration(x)+A6      call   ds:__imp__USB_ParseConfigurationDescriptorEx@28
SelectConfiguration(x)+AC      test   eax, eax
SelectConfiguration(x)+AE      jz     short loc_11770
SelectConfiguration(x)+B0      mov    al, [eax+5]
SelectConfiguration(x)+B3      mov    [esi+4], al
SelectConfiguration(x)+B6      jnp   short loc_11774
SelectConfiguration(x)+B8      ; -----
SelectConfiguration(x)+B8  loc_11770:                          ; CODE XREF: SelectConfiguration(x)+AE↑j
SelectConfiguration(x)+B8      nov   byte ptr [esi+4], 0 ; writes one null byte over the first byte of the next pool header
SelectConfiguration(x)+B8      ; this is where the corruption occurs
SelectConfiguration(x)+BC  loc_11774:                          ; CODE XREF: SelectConfiguration(x)+B6↑j
SelectConfiguration(x)+BC      movzx  eax, word ptr [esi]
SelectConfiguration(x)+BF      mov    ecx, [ebp+ptr_Pool_U802_24_bytes]
SelectConfiguration(x)+C2      add    esi, eax
SelectConfiguration(x)+C4      movzx  eax, byte ptr [edi+4]
SelectConfiguration(x)+C8      inc    ecx
SelectConfiguration(x)+C9      mov    [ebp+ptr_Pool_U802_24_bytes], ecx
SelectConfiguration(x)+CC      cmp    ecx, eax
SelectConfiguration(x)+CE      jb     short get_more_interfaces_to_parse
```

Analysis #1

When `bNumInterfaces = 3` (one more than it should be) and `bNumEndpoints = 2` (valid value)

Next kernel pool:

```
849c3b28 10 00 0a 04 56 61 64 6c-6b 8f 94 85 28 8c 90 85  ....Vadlk...(...
```

becomes:

```
849c3b28 00 00 0a 04 56 61 64 6c-6b 8f 94 85 28 8c 90 85  ....Vadlk...(...
```

So we're overwriting "PreviousSize" in the next `nt!_POOL_HEADER` - this is what triggered the original Bug Check when `ExFreePool()` is called



Analysis #2

When `bNumInterfaces = 3` (one more than it should be) and `bNumEndpoints = 5` (three more than it should be)

Next kernel pool:

```
84064740 17 00 03 00 46 72 65 65-48 2d 09 84 30 a8 17 84 ....FreeH-...0...
```

becomes:

```
84064740 17 00 03 00 00 72 65 65-48 2d 09 84 30 a8 17 84 .....reeH-...0...
```

So we're now overwriting "PoolTag" in the next `nt!_POOL_HEADER`



What's going on?

```
kd> dt nt!_POOL_HEADER
- +0x000 PreviousSize : Pos 0, 8 Bits
- +0x000 PoolIndex : Pos 8, 8 Bits
- +0x000 BlockSize : Pos 16, 8 Bits
- +0x000 PoolType : Pos 24, 8 Bits
- +0x004 PoolTag : Uint4B
- +0x008 ProcessBilled : Ptr64 _EPROCESS
```

By manipulating `bNumInterfaces` and `bNumEndpoints` in a USB Configuration descriptor we appear to have a degree of control over where in the next adjacent kernel memory pool I can overwrite a single byte with a null (the null write occurs four bytes after the end of the pool I control and I can also control its size and some elements of its contents so could also potentially overwrite the next pool header with something useful)



Some pseudo code

```
for (i=0; i<something->count; i++)
{
    list[i].descriptor = USBD_ParseConfigurationDescriptorEx (...);
    ...
    if (!list[i].descriptor)
        break;
}

list[i].descriptor = NULL;

newthing = USB_CreateConfigurationRequestEx(thing, list);

if(newthing)
{
    ptr = &newthing->somemember;
    for (i=0; i<something->count; i++)
    {
        descriptor = USBD_ParseConfigurationDescriptorEx (...);
        ...
        if(descriptor)
        {
            ptr->someothermember = descriptor->whatever;
        }
        else
        {
            ptr->someothermember = 0; // this is where I believe the corruption happens
        }
        ptr = ptr + ptr->Length;
    }
}
```


Challenges faced when exploiting USB bugs

- Lack of feedback channel
- The bug is often in kernel code
- Descriptors are generally very size-constrained
- Typical impact of USB exploitation typically restricted to privilege escalation
- What about USB over RDP?



Conclusions

- The USB enumeration phase reveals useful information for fingerprinting
- Class-specific communication is potentially even more revealing
- Even vendors with mature SDL processes have USB bugs
- USB bugs can potentially be exploited, to provide privilege escalation
- ...but it is extremely difficult to achieve reliably



Questions?

Andy Davis, Research Director NCC Group
andy.davis 'at' nccgroup 'dot' com

